

CRITICAL ITEMS LIST

SUBSYSTEM: SPACE TO SPACE COMMUNICATIONS SYSTEM

SYSTEM: EXTRAVEHICULAR MOBILITY UNIT

ASSEMBLY: SPACE TO SPACE EMU RADIO (SSER) ASS Y P/N: SED16102580

APPROVAL DATE:

SUPERCEDES REV: N/A DATE: N/A

SHEET 1 OF 1

INDIVIDUAL EFFECTIVITY: OV102, OV103, OV104, OV105 AND SUBS.

PREPARED BY: Name: A. Olson DATE: 12/06/96

APPROVAL:

SR&MA:

DESIGN

SSCS PROJECT MANAGER:

Mullen, Chay

DATE:

DATE: 6-30-97

DATE: 6/30/97

CRITICALITY(H/F): 2/IR

INTACT ABORT MODE CRIT: N/A

REDUNDANCY SCREENS: A-PASS B-PASS C-PASS

FMEA REFERENCE: SSER-22A

NAME: SSI.R

DRAWING REFERENCE: SED16102580, SED16102601, SED16102639, SU216102561

QUANTITY: 1

CI#	REV	FUNCTION	FAILURE MODE AND CAUSE	FAILURE EFFECT	RATIONALE FOR ACCEPTABILITY
SSER-22A	BASIC	<p>1. Provides RF Duplex voice communications between the EMU and Orbiter, other EMUs, and the Space Station</p> <p>2. Provides telemetry from EMU to Orbiter or Station</p> <p>3. Provides caution and status tone to CVA on command from EME, caution and warning system.</p> <p>4. Provides Handline voice communication between EMU and Orbiter or Station in Airlock</p> <p>MISSION PHASES</p> <p>MISSION: Pre-EVA</p> <p>EVA</p> <p>Post-EVA</p> <p>MISSION: Post-EVA</p>	<p>FAILURE MODE: Short of warning tone input</p> <p>CAUSE: Contamination, vibration, shock, EEE parts failure, or temperature cycle</p> <p>MISSION PHASES</p> <p>Pre-EVA</p> <p>EVA</p> <p>Post-EVA</p>	<p>SUBSYSTEM: Continuous warning tone in received audio in all modes. No caution tones. Transmit audio, binned and telemetry not affected in any mode</p> <p>INTERFACING SUBSYSTEMS: No effect</p> <p>MISSION: Crew member not alerted to read DCM display because warning tone is continuous.</p> <p>CREW/VEHICLE: No effect for first failure, or second failure (CO2 sensor failure) crew member may not be alerted to potentially hazardous situation.</p> <p>SUCCESS PATHS</p> <p>REMAINING AFTER FIRST FAILURE: 1</p> <p>TIME TO EFFECT: minutes</p>	<p>DESIGN: The electrical design of the SSER is based upon JSC in-house engineering model hardware. Luton is manufacturing the hardware in accordance with the appropriate NHB 5300.4 standards</p> <p>Passive EEE parts are selected from the guidelines of MIL-STD-975. Active EEE parts are approved by the JSC Engineering Directorate Certified Parts Approval Process.</p> <p>The Warning Tone input line is brought into the SSER through a Bendix 10-550354-35P miniature guide disconnect, bayonet lock connector. M22759 wire is run from the Bendix Connector to an EMI filter connector (36-726-402 from Spectrum Control) and then to the PRJ and ALT signal processors. Splices are made in accordance with Rockwell specification ME 16-0631-1004. The cables are tacked to avoid strain. The Warning Tone signal is brought to the Modem/Signal Processor Power converter for the Handline mode through a SAMTEC SSQ-112-23-S-D stackable connector. The Warning Tone circuits on the PRJ and ALT signal processors and the Modem/Signal Processor Power Converter are isolated through the use of QS3384 CMOS switches from Quality Semiconductor which are rated to operate from 55°C to 125°C. The PRJ and ALT and Modem/Signal Processor Power Converter (Handline Mode) each have their own tone generator. The SSER is environmentally sealed to avoid contamination.</p>

CRITICAL ITEMS LIST

SYSTEM: EXTRAVEHICULAR MOBILITY UNIT

SUBSYSTEM: SPACE TO SPACE COMMUNICATIONS SYSTEM

ASSEMBLY: SPACE TO SPACE EMU RADIO (SSER) ASS'Y P/N: SED16102580

APPROVAL DATE:

SUPERCEDES REV: N/A DATE: N/A

SHEET 2 OF 4

END ITEM EFFECTIVITY: OV102, OV103, OV104, OV105 AND SUBS.

PREPARED BY: Nanci A. Olson

DATE: 12/06/96

APPROVAL:

SR&MA:

DESIGN:

SSCS PROJECT MANAGER:

CRITICALITY(H/F): 2/1R

INTACT ABORT MODE CRIT: N/A

REDUNDANCY SCREENS: A-PASS B-PASS C-PASS

FMEA REFERENCE: SSER-22A

NAME: SSER

DRAWING REFERENCE: SED16102580, SID16102601, SID16102639, SID16102561

QUANTITY: 1

CIL #	REV	FUNCTION	FAILURE MODE AND CAUSE	FAILURE EFFECT	RATIONALE FOR ACCEPTABILITY
SSER-22A	BASIC	<p>1. Provides RF Duplex voice communications between the EMU and Orbiter, other EMUs, and the Space Station</p> <p>2. Provides telemetry from EMU to Orbiter or Station</p> <p>3. Provides caution and status tone to CCA on command from EMU caution and warning system.</p> <p>4. Provides Hardline voice communication between EMU and Orbiter or Station in Airlock</p>	<p>FAILURE MODE: Short of warning tone input</p> <p>CAUSE: Contamination, vibration, shock, EEE parts failure, or temperature cycle</p> <p>MISSION PHASES: Pre EVA EVA Post EVA</p>	<p>SUBSYSTEM: Continuous warning tone in received audio in all modes. No caution tones. Transmit audio, biomed and telemetry not affected in any mode.</p> <p>INTERFACING SUBSYSTEMS: No effect</p> <p>MISSION: Crew member not alerted to read DCM display because warning tone is continuous.</p> <p>CREW/VEHICLE: No effect for first failure. For second failure (CO2 sensor failure) crew member may not be alerted to potentially hazardous situation.</p> <p>SUCCESS PATHS REMAINING AFTER FIRST FAILURE: 1</p> <p>TIME TO EFFECT: minutes</p>	<p>DESIGN: (continued) The signal processor and modem/signal processor power converter boards are conformably coated to avoid contamination.</p> <p>TEST:</p> <p>CERTIFICATION: One time test on Qual SSER. Warning Tones are verified before and after exposure to environments in all modes.</p> <p>QUALIFICATION THERMAL VACUUM TEST: 7 cycles from 15F to 140F operating and 1 cycle to -65F non-operating. Chamber evacuated to 1×10^{-7} torr throughout test. Warning tones are verified before and after test.</p> <p>SHOCK: Bench handling 4 inch drop test on each corner.</p> <p>Landing shock and acceleration environments certified by analysis.</p>

CRITICAL ITEMS LIST					
SYSTEM: EXTRAVEHICULAR MOBILITY UNIT		SUBSYSTEM: SPACE TO SPACE COMMUNICATIONS SYSTEM			
ASSEMBLY: SPACE TO SPACE EMU RADIO (SSER)		ASS'Y P/N: SED16102580			
		APPROVAL DATE: SUPERCEDES REV: N/A DATE: N/A SHEET 3 OF 4			
END ITEM EFFECTIVITY: OV102, OV103, OV104, OV105 AND SUBS					
PREPARED BY: Nanci A. Olson		DATE: 12/06/96			
APPROVAL:					
SR&MA: _____		DATE: _____			
DESIGN: _____		DATE: _____			
SSCS PROJECT MANAGER: _____		DATE: _____			
CRITICALITY(H.F): 2/1R		INTACT ABORT MODE CRIT: N/A			
REDUNDANCY SCREENS: A-PASS B-PASS C-PASS					
FMEA REFERENCE: SSER-22A					
NAME: SSER					
DRAWING REFERENCE: SED16102580, SID16102601, SID16102639, SID16102561					
QUANTITY: 1					
CIL #	REV	FUNCTION	FAILURE MODE AND CAUSE	FAILURE EFFECT	RATIONALE FOR ACCEPTABILITY
SSER-22A	BASIC	1. Provides RF Duplex voice communications between the EMU and Orbiter, other EMUs, and the Space Station 2. Provides telemetry from EMU to Orbiter or Station 3. Provides caution and status tone to CCA on command from EMU caution and warning system. 4. Provides Hardline voice communication between EMU and Orbiter or Station in Airlock MISSION PHASE: Pre-EVA, EVA, Post-EVA	FAILURE MODE: Short of warning tone input CAUSE: Contamination, vibration, shock, EEE parts failure, or temperature cycle MISSION PHASES: Pre-EVA, EVA, Post-EVA	SUBSYSTEM: Continuous warning tone in received audio in all modes. No caution tones. Transmit audio, biomed and telemetry not affected in any mode. INTERFACING SUBSYSTEMS: No effect MISSION: Crew member not alerted to read DCM display because warning tone is continuous. CREW/VEHICLE: No effect for first failure. For second failure (CO2 sensor failure) crew member may not be alerted to potentially hazardous situation. SUCCESS PATHS REMAINING AFTER FIRST FAILURE: 1 TIME TO EFFECT: minutes	TEST: (CONTINUED) VIBRATION - Test-induced (QAVT) - 5 minutes per axis. 20 to 80 Hz - increasing 3 dB/oct 80 to 350 Hz - constant 0.067 g ² /Hz 350 to 2000 Hz - decreasing 3 dB/oct Flight-induced - 24 minutes per axis 20 to 150 Hz - increasing 6 dB/oct 150 to 1000 Hz - constant 0.03 g ² /Hz 1000 to 2000 Hz - decreasing 6 dB/oct Warning tone verified before and after each vibration test. Salt-fog, humidity, and fungus certified by analysis to requirements of JSC26789 (SSER Specification)
					ACCEPTANCE: TEMPERATURE - One and one-half cycles from 20F to 120F. Warning tone verified before and after temperature exposure. VIBRATION - 1 Minere per axis minimum 20 to 80 Hz - increasing 3 dB/oct 80 to 350 Hz - constant 0.04 g ² /Hz 350 to 2000 Hz -decreasing 3 dB/oct Warning tone output measured before and after each axis.

CRITICAL ITEMS LIST

SUBSYSTEM: SPACE TO SPACE COMMUNICATIONS SYSTEM

SYSTEM: EXTRAVEHICULAR MOBILITY UNIT

ASSEMBLY: SPACE TO SPACE EMU RADIO (SSER)

ASSY P/N: SED16102580

END ITEM EFFECTIVITY: OV102, OV103, OV104, OV105 AND SUBS.

PREPARED BY: Nanci A. Olson

DATE: 12/06/96

APPROVAL DATE:

SUPERSEDES REV: N/A DATE: N/A

SHEET 4 OF 4

APPROVAL:

SR&MA:

DATE:

DESIGN:

DATE:

SSCS PROJECT MANAGER:

DATE:

CRITICALITY(H/F): 2/IR

INTACT ABORT MODE CRIT: N/A

REDUNDANCY SCREENS: A-PASS B-PASS C-PASS

FMEA REFERENCE: SSER-22A

NAME: SSER

DRAWING REFERENCE: SED16102580, SID16102601, SID16102639, SID16102561

QUANTITY: 1

CIL #	REV	FUNCTION	FAILURE MODE AND CAUSE	FAILURE EFFECT	RATIONALE FOR ACCEPTABILITY
SSER-22A	BASIC	<p>1. Provides RF Duplex voice communications between the EMU and Orbiter, other EMUs, and the Space Station</p> <p>2. Provides telemetry from EMU to Orbiter or Station</p> <p>3. Provides caution and status tone to CCA on command from EMU caution and warning system.</p> <p>4. Provides Hardline voice communication between EMU and Orbiter or Station in Airlock</p> <p>MISSION PHASE: Pre-EVA, EVA, Post-EVA</p>	<p>FAILURE MODE: Short of warning tone input</p> <p>CAUSE: Contamination, vibration, shock, EEE parts failure, or temperature cycle</p> <p>MISSION PHASES: Pre EVA, EVA, Post EVA</p>	<p>SUBSYSTEM: Continuous warning tone in received audio in all modes. No caution tones. Transmit audio, biomed and telemetry not affected in any mode.</p> <p>INTERFACING SUBSYSTEMS: No effect</p> <p>MISSION: Crew member not alerted to read DCM display because warning tone is continuous.</p> <p>CREW/VEHICLE: No effect for first failure. For second failure (CO2 sensor failure) crew member may not be alerted to potentially hazardous situation.</p> <p>SUCCESS PATHS REMAINING AFTER FIRST FAILURE: 1</p> <p>TIME TO EFFECT: minutes</p>	<p>TEST: (continued)</p> <p>PREINSTALLATION ACCEPTANCE TEST - Performed periodically at JSC prior to delivery of SSER for EMU installation. Includes complete electrical performance with warning tone outputs verified</p> <p><u>GROUND TURNAROUND TEST:</u> Turnaround checkout testing is accomplished in accordance with the OMRSD (V66). Functional verification of tone generators when suit is powered up, but no verification of warning tone input.</p> <p>INSPECTION: The SSER is manufactured in accordance with an approved Quality Assurance Plan. Subassemblies are inspected for conformance with released drawings and standards for parts placement, soldering, and cleanliness.</p> <p>FAILURE HISTORY: NONE. There have been no failures of this type through qualification and initial flight unit production. Current data on test failures, flight failures, unexplained anomalies, and other failures experienced during ground processing activity can be found in the PRACA database</p> <p>OPERATIONAL USE: Real Time Data System allows ground monitoring of EMU status. EVA timeline procedures require periodic EMU systems status checks by viewing DCM. Since failure of warning tone is known, checks of status data are made more frequently. Flight rules define operational caution and warning System.</p>